

Terminal-connection diagram

Terminal strip =97+UB.72-K45.1-X1										-End of terminal-									
Main part	Target	Wire connection		Level	Connection	Wire Jumper	Number	Wire Jumper	Connection	Wire connection	Target	Wire connection	Target	Wire connection	Target	Wire connection	Target	Wire connection	Target
ZDK 1,5	=97+UB.72-K45.1-J1-A	A-1	451801,05	1	2		1			1	451801,06	451801,06	=45+UB.72-18Y1-XG01/1,01	3					
	=97+UB.72-K45.1-J1-A	A-2	451802,05	2	4		1			3	451802,06	451802,06	=45+UB.72-18Y1-XG01/1,01	1					
	=97+UB.72-K45.1-J1-A	A-3	451803,05	1	2		2			1	451803,06	451803,06	=45+UB.72-18Y1-XG01/1,01	2					
ZDK 1,5	=97+UB.72-K45.1-J1-A	B-1	451804,05	2	2		2			1	451804,06	451804,06	=45+UB.72-18Y2-XG01/2,01	3					
	=97+UB.72-K45.1-J1-A	B-2	451805,05	1	4		3			3	451805,06	451805,06	=45+UB.72-18Y2-XG01/2,01	1					
	=97+UB.72-K45.1-J1-A	B-3	451806,05	2	2		3			1	451806,06	451806,06	=45+UB.72-18Y2-XG01/2,01	2					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	1	301002,200	1	2		4			1	301002,199	451095,37	=45+UB.72-23S1-XB12/1	2					
	=97+UB.72-K45.1-J1-CD	2	451095,68	2	4		4			3	451095,37	451095,37	=45+UB.72-23S1-XB12/1	3					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	3	452301,07	1	2		5			1	452301,01	452301,01	=45+UB.72-23S1-XB12/1	4					
	=97+UB.72-K45.1-J1-CD	4	452302,03	2	4		5			3	452302,01	452302,01	=45+UB.72-23S1-XB12/1	5					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	5	452310,07	1	2		6			1	452310,01	452310,01	=45+UB.72-23S1-XB12/1	6					
	=97+UB.72-K45.1-J1-CD	6	451095,70	2	4		6			3	451095,38	451095,38	=45+UB.72-23S1-XB12/1	7					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	7	301002,214	1	2		7			1	301002,213	451095,84	=45+UB.72-25S2-XB20/1	2					
	=97+UB.72-K45.1-J1-CD	8	451095,47	2	4		7			3	451095,84	451095,84	=45+UB.72-25S2-XB20/1	7					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	9	452503,01	1	2		8			1	452503,07	452503,07	=45+UB.72-25S2-XB20/1	6					
	=97+UB.72-K45.1-J1-CD	10	452511,01	2	4		8			3	452511,07	452511,07	=45+UB.72-25S2-XB20/1	3					
ZDK 1,5	=97+UB.72-K45.1-J1-CD	11	452504,01	1	2		9			1	452504,03	452504,03	=45+UB.72-25S2-XB20/1	4					
	=97+UB.72-K45.1-J1-CD	12	451095,48	2	4		9			3	451095,86	451095,86	=45+UB.72-25S2-XB20/1	5					
ZPE 1,5	=97+UB.72-K45.1-J1-A	B-SH	SH		2		10			1	SH	SH	=45+UB.72-18Y2-XG01/2,01	SH					
ZPE 1,5	=97+UB.72-K45.1-J1-A	A-SH	SH		2		11			1	SH	SH	=45+UB.72-18Y1-XG01/1,01	SH					